

PLANO DE ESTACIONAMIENTO Y ATRAQUE DE AERONAVES/
AIRCRAFT PARKING/DOCKING CHART

ELEV AD 1521 M

TWR 118.3
APP 121.1
FPQ 122.30

OAXACA
AEROPUERTO INTL. /
INTL. AIRPORT

2008
VAR. MAGNETICA, 5° E
MAGNETIC VAR. 5° E

ELEVACIONES Y DIMENSIONES EN METROS /
ELEVATIONS AND DIMENSIONS IN METERS

CALLES DE RODAJE, ANCHO, RESISTENCIA /
TAXIWAYS, WIDTH, STRENGTH

TWY	ANCHO / WIDTH	RESISTENCIA / STRENGTH	TIPO / TYPE
A	23 M	57 F/A/X/T	ASFALTO / ASPHALT
B			
C	18 M		
D			

LAS MARCACIONES SON MAGNETICAS /
BEARINGS ARE MAGNETIC

ESCALA / SCALE : 1 : 2500

0 20 40 60 M

ZONA SIN VISIBILIDAD DESDE TWR, PRECAUCION AL TRANSITAR
ZONE OUT OF SIGHT FOR TWR, PROCEED CAUTIOUSLY

CAMBIO/ CHANGES: POSICIONES/ POSITIONS

**COORDENADAS INS DE PUESTOS DE ESTACIONAMIENTO DE AERONAVES AVIACION COMERCIAL /
COORDINATES INS, FOR AIRCRAFT STANDS, COMMERCIAL AVIATION**

POSICION/ POSITION		LAT (N)	LONG (W)
P01	P01A	17° 00' 06.32"	096° 43' 20.01"
	P01B	17° 00' 06.40"	096° 43' 20.33"
	P01C	17° 00' 06.78"	096° 43' 21.72"
P02	P02A	17° 00' 04.93"	096° 43' 20.38"
	P02B	17° 00' 05.03"	096° 43' 20.75"
	P02C	17° 00' 05.40"	096° 43' 22.11"
P03	P03A	17° 00' 03.69"	096° 43' 20.52"
	P03B	17° 00' 03.72"	096° 43' 20.86"
	P03C	17° 00' 03.83"	096° 43' 22.33"
P04	P04A	17° 00' 02.54"	096° 43' 20.42"
	P04B	17° 00' 02.49"	096° 43' 20.77"
	P04C	17° 00' 02.27"	096° 43' 22.27"
P05	P05A	17° 00' 01.41"	096° 43' 20.11"
	P05B	17° 00' 01.25"	096° 43' 20.55"
	P05C	17° 00' 00.79"	096° 43' 21.88"
P05A	P5AA	17° 00' 01.68"	096° 43' 20.45"
	P5AB	17° 00' 01.18"	096° 43' 20.47"
	P5AC	16° 59' 58.78"	096° 43' 20.73"
P06	P06A	17° 00' 00.22"	096° 43' 19.49"
	P06B	17° 00' 00.04"	096° 43' 19.78"
	P06C	16° 59' 59.25"	096° 43' 21.08"